

Operating/assembly instructions for Minitramp

Thank you very much for choosing a **Sport-Thieme** product. We want to make sure that you can enjoy this product, so here is some important advice for your safety as well as for the use and maintenance of the equipment.

Please read these instructions fully before you assemble and use the equipment.



1. Assembly and adjustment

Tools: no tools are required for assembly. A Minitramp can be assembled by someone who is familiar with the instructions.

- To fold out the legs, place the trampoline vertically so both feet are freely moveable.
- Pull the legs into the desired position.
- Each of the telescopic support struts is tensioned by a steel spring.
- Pull the struts to lock them in the respective sleeve on frame and feet.
- Adjust the height of the trampoline surface using the star grip on the foot support.

2. Transport and storage

The folded trampolines can either be carried by hand or transported on a suitable trolley. The trampolines should be stored in an equipment room with restricted access. Please ensure that no sharp or pointed objects are leaning against the trampoline. This could cause damage to the trampoline bed and the padding. We recommend using the Eurotramp transport trolley for transport and storage (for max. 8 Minitramps).

Required space for Minitramp 112 (122 8104) and Minitramp 125 (122 8205)

Assembled dimensions:	112x112 cm	and	125x125 cm
Dimensions when stored:	112x112x10 cm	and	125x125x10 cm when folded

3. Check before each use

The trampolines should be checked for possible damage before every use. Ensure in particular that padding, trampoline bed, springs and frame parts are not damaged. Replace any faulty or missing parts. Repair damage immediately. If in doubt whether the trampoline is fit for use, it should always be checked by an expert (e.g. equipment manager or maintenance firm). The trampolines should be checked to ensure that they are in perfect technical condition by the respective maintenance firms, which service the sports halls at regular intervals.

In particular, ensure that:

- there is no damage to the bed
- the bed's suspension is in perfect condition
- there are no tears or other damage to the frame
- the springs are not damaged or overstretched
- the springs are attached to the frame and the bed with the eyelets facing downwards
- the coverall frame pads are properly attached
- the floor protectors are in working order

4. Maintenance and repair measures.

- Replace damaged floor protectors.
- Replace overstretched and worn springs. It is important to attach the springs with the eyelet facing downwards.
- The trampoline bed can be washed according to the following washing instructions. Remove the attachment pins from the bed and cover the corner rings with a piece of cloth to prevent scratches and damage to the washing machine. Wash at 30° with a detergent suitable for synthetics. Attach the wet bed to the trampoline frame and dry folded out as it will shrink otherwise. Failure to do so can make the bed unusable.

5. Use

Only use the trampoline under supervision!

Operating/assembly instructions
Minitramp
Prod. code: 122 8104 - Minitramp 112
122 8205 - Minitramp 125

SPORT-THIEME[®]
Schulsport · Vereinssport · Fitness · Therapie
38367 Grasleben - Tel. 05357 - 181 81
www.sport-thieme.de



Maintenance and care instructions

Instructions:

Carry out a visual check at regular intervals. Due to our continuous quality control of the products, technical changes may occur which may lead to slight deviations in the instructions. Check at regular intervals that the screw connections are tight. Check the equipment for possible damage and replace worn-out parts.

We are happy to answer any questions
you may have.

Your **Sport-Thieme** Team